

Manual, Assembly instruction: Brodit 855964

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the upper edge of the mount into the gap between the air vent housing and the dashboard,

2. Press forward on the lower part of the mount so the lower edge hooks/snaps over the frame surrounding the air vent.

3. The mount may be placed on the left center air vent.

4. The ProClip mount is in place.