

Manual, Assembly instruction: Brodit 855969

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place. It is important to install the mount in the exact same position as shown on the pictures.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hold the mount so the right side is aligned with the center of the power button above.

2. At first, press one corner of the lower edge of the mount into the gap between the frame surrounding the air vent and the trim. Then press all of the lower edge into the gap.

3. Press the top of the top frame surrounding the air vent slightly upwards. Press forward on the upper part of the mount so the edge goes into the gap behind the top frame. Adjust the mount sideways until the upper edge sits fully in the gap, placed between the notches in the gap.

4. The ProClip mount is in place.