

Manual, Assembly instruction: Brodit 855970

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the long upper part of the mount over the back edge of the dashboard panel just in front of the windshield
2. Pull the lower edge of the mount over the edge of the dashboard panel.
3. Hook the lower edge into place over the edge of the dashboard panel.
4. The ProClip mount is in place. The mount can be installed on the left or right side of the screen.