

Manual, Assembly instruction: Brodit 855973

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the upper edge of the mount under the frame surrounding the screen.

2. Press forward on the lower edge of the mount so the lower edge hooks/clips into the gap between the air vent housing and the surrounding frame.

3. The ProClip mount is in place.

4. The ProClip mount is in place.