

Manual, Assembly instruction: Brodit 855974

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the upper edge of the mount under/behind the frame surrounding the air vent.
2. Press upward and forward on the lower part of the mount so the edge hooks/snaps over the frame surrounding the air vent.
3. The ProClip mount is in place.
4. The mount may be placed on either center air vents.