

Manual, Assembly instruction: Brodit 855977

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Place the included gap opener to the right of the center air vents. Press the thin angled edge of the gap opener into the gap between the air vent housing and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover.

2. Place the lower edge of the mount into the gap next to the gap opener. Pull out to the gap opener.

3. Press downward and forward on the top of the mount. Hook/clip the upper edge into the upper gap of the vent housing. Press on the inside of the upper and lower lips to ensure they are fully inserted into the gaps and the adhesive tape makes full contact with the dashboard.

4. The ProClip mount is in place.