

Manual, Assembly instruction: Brodit 855978

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Press the thin end of the included Gap Opener (Spaltöffner) into the gap between the padded dashboard and the air vent housing.
2. Center the mount over the right vent. Place the upper edge of the mount in the gap next to the Gap Opener (Spaltöffner).
3. Press up on the bottom stem of the mount. Press forward on the face of the mount until the bottom lip clips into place. Ensure the bottom lip rests so it conforms to the contour of the accent panel and the upper lip is fully seated in the top seam. Pull out the Gap Opener (Spaltöffner).
4. The ProClip mount is in place.