

Manual, Assembly instruction: Brodit 855979

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the mount to the left of the screen so the lower edge is positioned as shown in the picture. Hook the upper edge of the mount over the screen.

2. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the air vent housing and the surrounding frame, to widen the gap.

3. Press down and forward on the mount until the lower edge clips + snaps into the gap next to the Gap Opener (Spaltöffner). Press on the top and bottom of the mount to ensure the mount is fully seated and installed square to the dashboard. Pull out the Gap Opener (Spaltöffner).

4. The ProClip mount is in place.