

Manual, Assembly instruction: Brodit 855980

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the mount first: any holder & equipment is to be attached after the mount is in place.

1. Shift the right air vent louver control all the way to the left. Press the thin end of the enclosed gap opener into the gap between air vent housing and the surrounding frame directly above the louver control, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover on the mount.

2. Hook the grooved edge on the lower part of the mount over the frame surrounding the air vent.

3. Press the upper part of the mount downward/forward and hook the angled edge on the upper part into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip mount is in place.