

Manual, Assembly instruction: Brodit 855983

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the lower edge of the mount onto the air vent frame.
2. Press the upper part of the mount downward and forward so the upper edge goes into the gap between the air vent housing and the air vent frame,
3. Press downwards and upwards on the inside of the mount so the adhesive tapes attach properly.
4. The ProClip is in place.