

## Manual, Assembly instruction: Brodit 855987

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.**

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the thin ends of the enclosed Gap Opener (Spaltöffner)s into the gap between the center console trim and the dashboard, to widen the gap. Place the lower edge of the mount into the gap between the Gap Opener (Spaltöffner)s.

2. Pull the top of the mount upward and press forward. Hook the upper edge of the mount over the frame surrounding the air vent. Press forward on the bottom of the mount until the lower edge clips + hooks behind the dashboard. Pull out the Gap Opener (Spaltöffner)s.

3. The mount may be placed on either air vent.

4. The ProClip mount is in place.