

Manual, Assembly instruction: Brodit 855988

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower edge of the mount over the frame surrounding the air vent.
2. Press + wiggle the mount forward so the upper edge clips + hooks under the frame surrounding the air vent.
3. Gently press upward and downward on the mount to ensure it is properly in place.
4. The ProClip mount is in place.