

Manual, Assembly instruction: Brodit 855989

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place/Hook the upper edge of the mount under the air vent housing top.
2. Press the lower part of the mount upwards and forwards so the edge hooks/clips over the air vent housing bottom.
3. Press upward and downward inside the upper and lower parts of the mount so it is properly in place.
4. The ProClip is in place. The mount may be installed on either center air vent