

Manual, Assembly instruction: Brodit 855990

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the mount over the screen. Flex/Pull the sides apart. Press/slide the mount downwards and hook the sides around the screen.
2. Press the mount downward so it hooks all the way around the screen.
3. Press on the mount until it is properly in place.
4. The ProClip mount is in place.