

Manual, Assembly instruction: Brodit 855994

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower edge of the mount over the frame surrounding the air vent.

2. Adjust the mount into the position shown in the picture. The right edge should align with the curved line on the trim.

3. Press downwards and forwards on top of the mount so the upper edge hooks/clips under the frame surrounding the air vent. Press upwards and downwards on the inside of the upper and lower part so the mount is properly seated.

4. The ProClip mount is in place.