

Manual, Assembly instruction: Brodit 855998

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Press the thin end of the included gap opener into the gap between the air vent housing and the surrounding frame, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the angled edge on the upper part of the mount into the opened gap. Pull out the gap opener.

2. Press forward on the lower part of the mount so the lower edge snaps/hooks into the bottom of the air vent.

3. The mount may be installed on either side of the center air vents.

4. The ProClip mount is in place.