

Manual, Assembly instruction: Brodit 856000

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Press the thin ends of the included gap openers into the gap between the frame surrounding the air vent housing and the trim below it, to widen the gap. Place one under the hazard lights button and one under the right corner of the air vent. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover.

2. Press the lower edge of the mount into the gap between the gap openers. Pull out the gap openers.

3. Press the upper part of the mount downward and forward. Clip/Hook the upper edge into the gap between the air vent housing and the dashboard trim. Press downward and upward inside the mount so the adhesive tapes make full contact with the dashboard.

4. The ProClip mount is in place.