

Manual, Assembly instruction: Brodit 856001

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place. This mount consists of two parts.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the smaller part of the mount behind the console frame, on the right side.
2. Hook the mount face plate over the console frame. Adjust the position over the smaller part so the holes align. Press and hold the two parts together.
3. Use a Phillips screwdriver to secure the parts together with the included screws.
4. The ProClip mount is in place.