

Manual, Assembly instruction: Brodit 856005

Center mount

1.)

2.)



3.)

4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Position the mount in front of the right air vent, so the faceplate angles toward the driver. Hook the lower edge of the mount onto frame surrounding the air vent.

2. Press forward on the upper part of the mount, so the upper edge hooks + snaps under the frame surrounding the air vent.

3. Press upwards + downwards on the inside of the lower + upper parts of the mount, so the mount is properly in place.

4. The ProClip mount is in place.