

Manual, Assembly instruction: Brodit 856006

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place. It is important to attach this mount in the exact same position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the mount so it rests just below the angle in the center console wall. Press the left edge of the mount into the gap between the control panel frame and the center console wall.

2. Press forward on the right side of the mount faceplate so the right edge hooks/snaps behind the center console side wall.

3. The ProClip mount is in place.

4. The ProClip mount is in place.