

Manual, Assembly instruction: Brodit 856007

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the bottom of the mount on the bottom housing of the air vent.
2. Press forward on the top of the mount until the upper edge hooks + clips on to the air vent housing.
3. The ProClip mount is in place.
4. The ProClip mount is in place.