

Manual, Assembly instruction: Brodit 856011

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the included alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape covers. Hook the angled edge on the upper part of the mount over the trim.
2. Press forward on the lower part of the mount so the lower edge hooks into the gap in the dashboard.
3. Press forward on the lower part so the edge goes all the way into the gap and the adhesive tapes attach.
4. The ProClip is in place.