

Manual, Assembly instruction: Brodit 856014

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Press the included Gap Opener (Spaltöffner) into the gap between the air vent housing and the surrounding dashboard panel, to widen the gap.
2. Press the lower edge of the mount into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).
3. Press downward and forward on top of the mount. Hook + Clip the upper edge into the gap between the air vent housing and the dashboard panel.
4. The ProClip mount is in place.