

Manual, Assembly instruction: Brodit 856016

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Press the thin end of the included gap opener into the gap on top of the dashboard., to widen the gap. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover.

2. Press the lower edge of the mount into the gap between the center panel and the dashboard. Press upward on the bottom of the mount so the edge goes all the way into the gap.

3. Pull the upper part of the mount upward and press it forward. Hook the upper edge of the mount into the gap next to the gap opener. Press down on top of the mount so the edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip mount is in place. The mount may be placed as desired within the width of the center panel, provided the installed device/equipment will not block view/access.