

Manual, Assembly instruction: Brodit 856021

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape covers. Hook the upper edge of the mount under the inner top of the air vent housing.

2. Press the lower edge of the mount upward and forward. Hook the lower edge over the inner bottom of the air vent housing.

3. Press on the mount so the adhesive tapes attach. This mount can also be placed onto the left air vent, provided that the device you wish to install will not interfere with the view of the screen.

4. The ProClip is in place.