

Manual, Assembly instruction: Brodit 856027

Center mount Only For 12.9" Screen.



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Press the thin end of the enclosed gap opener into the gap between the center console and the dashboard. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover.

2. Press the upper edge of the mount into the gap next to the gap opener. Pull out the gap opener.

3. Press the lower part of the mount upward and forward. Hook the grooved lower edge over the frame surrounding the air vent.

4. The ProClip is in place.