

Manual, Assembly instruction: Brodit 856030

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the lower edge of the mount onto the frame surrounding the air vent.
2. Press the upper part of the mount downward and forward. Press the upper part forward so the edge hooks/snaps under the frame surrounding the air vent.
3. The mount can be placed anywhere within the width of the air vent provided the installed device/equipment will not interfere with view or access.
4. The ProClip mount is in place.