

Manual, Assembly instruction: Brodit 856033

Center mount For models with 10,5" display.



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Press the thin end of the included gap opener into the gap between the control panel and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape covers. Hook the upper edge of the mount over the frame surrounding the air vent.

2. Pull the lower part of the mount downward and hook the edge into the gap next to the gap opener.

3. Press upward on the lower part of the mount so the edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip mount is in place. The mount can be positioned anywhere within the width of the air vent.