

Manual, Assembly instruction: Brodit 856041

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the lower edge of the mount into the gap between the screen and the surrounding frame.

2. Pull the upper part of the mount upward and hook the upper edge into the gap between the control panel and the dashboard.

3. Press on the mount so it sits properly in place and the adhesive tape attaches.

4. The ProClip mount is in place.