


Manual, Assembly instruction: Brodit 856053

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any device holder & equipment is to be attached after the mount is in place.

1. Hold the mount over the screen so the face plate is placed onto the drivers side of the screen.
2. Slowly and firmly, press down on both sides of the mount to slide/hook it onto the screen. Press downward until the mount is securely in place.
3. The ProClip mount is in place.
4. The ProClip mount is in place.