

Manual, Assembly instruction: Brodit 856054

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place. This mount consists of two parts.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the trim, to widen the gap. Place the larger mount above the gap and press it downward so the lower edge goes into the gap next to the gap opener. Press downward so the lower edge goes all the way into the gap. Pull out the gap opener.

2. Place the smaller mount part onto the upright part behind the face plate. Press/slide the smaller part upward so it rests underneath/against the dashboard overhang.

3. Keep the parts in position and attach them together with the enclosed screws.

4. The ProClip mount is in place.