Manual, Assembly instruction: Brodit 856061

Angled mount

1.)

2.)

3.)

4.)

Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Place the mount behind the screen, above the center console.

2. Slowly and firmly, press down on both sides of the mount to slide/hook it onto the center console

3. Press downward until the mount is securely in place.

4. The ProClip mount is in place.