

Manual, Assembly instruction: Brodit 856072

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hold the mount over the screen so the face plate is placed on the drivers side of the screen.

2. Press the sides out slightly on the ProClip. Place the ProClip over the screen and press downward until the mount is securely in place. Squeeze the sides against the screen.

3. The ProClip mount is in place.

4. The ProClip mount is in place.