

Manual, Assembly instruction: Brodit 856078

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Press the thin end of the included gap opener into the gap between the frame surrounding the display and the dashboard, to widen the gap. Press the upper edge of the mount into the gap next to the gap opener. Pull out the gap opener.

2. Press the lower part of the mount forward and upward. Hook the angled edge into the gap between the frame surrounding the air vent and the dashboard.

3. This mount can be placed anywhere within the width of the control panel.

4. The ProClip is in place.