

Manual, Assembly instruction: Brodit 856084

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower edge of the mount into the gap between the air vent housing and the frame surrounding the air vent.
2. Press downward on top of the mount and press it forward. Hook the upper edge of the mount into the gap between the air vent housing and the frame surrounding the air vent.
3. Press on the mount so the adhesive tape attaches properly.
4. The ProClip mount is in place.