

Manual, Assembly instruction: Brodit 856098

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Position the mount on the right side of the center air vents. Hook the lower edge on the inside of the air vent housing.
2. Press forward on the middle of the mount until the upper edge hooks + clips under the air vent frame
3. Press on the inside of the mount to ensure the tape makes full contact with the dashboard.
4. The ProClip mount is in place.