

Manual, Assembly instruction: Brodit 856100

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the thin end of the included Gap Opener (Spaltöffner) into the gap between the air vent housing and the surrounding frame, to widen the gap.

2. Center the mount under the right air vent. Press the lower edge into the gap between the climate controls panel and the dashboard panel.

3. Pull the upper part of the mount upward, over the dashboard panel. Press forward on the top of the mount so the upper edge hooks + snaps into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).

4. The ProClip mount is in place.