

Manual, Assembly instruction: Brodit 856102

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the longer, upper edge of the mount inside the upper air vent frame.
2. Press forward on the bottom of the mount until the lower edge clips + hooks onto the air vent frame.
3. Press on the mount so the adhesive tape attaches properly.
4. The ProClip mount is in place.