

Manual, Assembly instruction: Brodit 856106

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place. This mount consists of two parts: An attaching piece and a faceplate.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the attaching piece behind the faceplate as shown in the picture. Screw the parts together by hand using the included screws, do not tighten the screws yet. Hook the upper edge of the mount under the dashboard overhang. Hook the lower edge of the faceplate behind the screen.

2. Press on the mount to securely adhere the adhesive tape. Tighten the screws so the mount is properly in place.

3. The mount may be placed anywhere within the width of the air vent.

4. The ProClip mount is in place.