

Manual, Assembly instruction: Brodit 856110

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Hold the face plate so the holes are placed on the upper half. Place the smaller part onto the back of the plate so the angle is pointing downwards. Attach the two parts together with the enclosed screws. NOTE: Do not tighten the screw, only attach the two parts together leaving a few millimeter space between them.

2. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the mount in front of the air vent. Hook the angled edge of the mount over the frame surrounding the air vent so the lower edge rests under the dashboard overhang.

3. Tighten the screws so the mount sits properly in place.

4. The ProClip mount is in place.