

Manual, Assembly instruction: Brodit 856112

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Fit the two sides of the mount together.

2. Align the joining plate with the threaded inserts and secure the mount together using the included screws.

3. Place the mount over the screen so the face plate is on the drivers side of the screen. Flex the sides of the mount open, and slide it downward, over the screen. Press downwards on one side of the time and slide the mount downward until the top of the mount is flush with the top of the display frame.

4. The ProClip mount is in place.