

Manual, Assembly instruction: Brodit 856114

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Gently place the mount onto the dashboard overhang. Hook the angled upper edge over the dashboard overhang.

2. Press downward on top of the mount so the angled edge goes into the gap behind the dashboard.

3. Press forward on the lower part of the mount so the angled lower edge hooks into place properly behind the dashboard.

4. The ProClip mount is in place. The mount may be placed as desired within the width of the center air vents, provided the mounted device/equipment does not obstruct visibility and access.