

Manual, Assembly instruction: Brodit 856117

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Hold the left edge of the mount aligned along the right edge of the screen. Press the upper edge of the mount into the gap between the frame surrounding the screen and the dashboard panel. Hook the edge behind the dashboard panel.

2. Pull the lower part of the mount downward so the mount opens a bit. Hook the lower edge under the dashboard panel edge.

3. The ProClip mount is in place.

4. The ProClip mount is in place.