

Manual, Assembly instruction: Brodit 856121

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Press the thin end of the included gap opener into the gap between the frames surrounding the air vent and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the angled edge on the upper part of the mount into the gap next to the gap opener. Pull out the gap opener.

2. Pull the lower part of the mount downward and hook the angled lower edge into the gap between the frame surrounding the air vent and the trim.

3. Press on the upper and lower parts of the mount so the angled edges go into the gaps properly and the adhesive tapes attach.

4. The ProClip mount is in place. This mount can be placed in any location within the width of the air vent provided that the device/equipment you wish to install will not interfere with the view of the screen or access of buttons.