

Manual, Assembly instruction: Brodit 856123

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the upper edge of the mount under the center panel edge.
2. Press forward on the lower part of the mount so the grooved lower edge hooks around the frame surrounding the air vent.
3. This mount can be placed anywhere within the width of the air vent.
4. The ProClip mount is in place.