

Manual, Assembly instruction: Brodit 856124

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Hold the mount so the faceplate is angled toward the driver. Place the mount immediately right of the screen.

2. Press forward on the top of the mount so the upper edge snaps into the gap between the cloth panel and the trim. You can push upward on the upper stem to assist installation.

3. Press forward on the lower part of the mount so the lower edge snaps into the gap between the cloth panel and the trim. You can push downward on the lower stem to assist installation. **4.** The ProClip mount is in place.