

Manual, Assembly instruction: Brodit 856127

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Fit the two large sections of the mount together.

2. Secure the two sections together using the included plate and machine screws. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover.

3. Hold the mount over the screen so the face plate is on the drivers side. Flex the edges outward and slide the mount downward over the sides of the screen. Continue working the mount downward, one side after the other, until it sits on the back of the screen. Ensure the edges are sitting even on each side of the screen and the tape makes full contact with the frame.

4. The ProClip mount is in place.