

Manual, Assembly instruction: Brodit 856129

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place. This mount consist of two parts: a faceplate and a mount.

1. Hook the left faceplate edge behind the trim surrounding the center panel.
2. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the center console frame and the sidewall, to widen the gap just below the faceplate. Press the lower part of the mount edge into the gap above the Gap Opener (Spaltöffner). Work upwards so all of the edge goes all the way into the gap. Pull out the Gap Opener (Spaltöffner).
3. Adjust the face plate so the holes match the holes on the mount. Fasten the parts together using the included screws.
4. The ProClip mount is in place.