

Manual, Assembly instruction: Brodit 856136

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the upper edge of the mount into the top edge of the air vent housing.
2. Press forward on the bottom of the mount until the lower lip clips onto the bottom of the air vent housing.
3. The mount may be installed on either center air vent.
4. The ProClip mount is in place.