

Manual, Assembly instruction: Brodit 856137

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower edge of the mount over the frame surrounding the air vent.
2. Press forward on the top of the mount until the upper edge hooks + clips under the frame surrounding the air vent.
3. The mount may be installed on both center air vents.
4. The ProClip mount is in place.